



Scan QR Code with your smart phone to see video instructions.


**Installation Instructions**  
**JLT Series 3 Cold Air Intake Kit – #CAI3-FMG-05; #CAI3-FMG05-P**

Thank you for purchasing our product. We hope you are satisfied with the look and performance. Take your time and it will be a smooth install. If you have any questions, contact us direct before going to the internet.


**ATTENTION: A tune specific for this intake is required when installing this kit. Failure to add a tune specific for the JLT intake may result in major engine damage.**  
**\*\*\*DO NOT INSTALL KIT AND DRIVE WITHOUT A TUNE! \*\*\***

Please review complete instructions prior to installing.

Step#	
1	<b>Verify you have all of the following parts included in the kit:</b> (1) JLT Plastic tube with PCV fitting, (1) Silicone Coupler 4.5" ID x 2", (1) 4.5x9" S&B Air Filter, (1) JLT Heat Shield, (1) PCV hose, (2) #72 Clamps, (2) MAF Screws (1) Bolt
2	<b>Gather all of the following tools needed for the installation:</b> 10mm socket, extension and ratchet, torx 20 driver, Phillips and flat head screw driver or 5/16 nut driver
3	<b>Install Tune for JLT Intake</b> – Refer to instructions included with Tuner.
4	Unplug your MAF sensor plug and remove the stock intake by loosening the clamp at the throttle body and removing the 10mm bolt holding down the airbox. Unhook the PCV line at the valve cover and lift up and out.
5	<p>Install JLT heat shield using the stock airbox bolt and replacing factory fan shroud bolt with supplied longer M6x1x25 bolt. <b>ON SOME MODELS</b> you will need to push in on coolant hose slightly to install shield as shown below :</p> <p><b>Remove factory 8mm bolt and use supplied 10mm Bolt to secure heat shield to radiator. Be sure heat shield mounting tab goes IN BETWEEN Radiator and fan should as shown below:</b></p>

6	<p>Remove the MAF sensor from the stock airbox using a torx T-20 driver and install in the JLT MAF housing using supplied Phillips head screws. Screws just need to be snug.</p> 
---	---

7	<p>Install coupler and clamps on to JLT tube and install on to throttle body then install air filter on to JLT tube as shown:  <b>** TIP ** Be sure to wipe any oil from the inside of air filter flange to avoid and slipping.</b></p> 
---	--

8	<p>Plug in MAF sensor and supplied PCV hose and you're DONE! <b>Do not tighten clamps more then finger tight!!</b></p> 
---	---

This kit includes an S&B Powerstack pre-oiled reusable air filter. The frequency you should clean your filter will depend on your driving conditions. It is recommended to check your filter at every oil change or 3,000 miles. If there is a build up of dirt as thick as the wire mesh, then it's time to clean your filter. As dirt builds up on your filter, the restriction of the airflow also increases. More frequent cleanings will improve your fuel economy and your vehicle's performance.

To properly clean your filter, we recommend the S&B Precision Cleaning & Oiling Kit (located in the Parts Sold Separately Section of our website, [www.JLTtruecoldair.com](http://www.JLTtruecoldair.com)).

Thanks for the business. If you have any questions, please e-mail [Jay@JLTtruecoldair.com](mailto:Jay@JLTtruecoldair.com) or call 757-335-1940. Our hours are Monday-Friday, 8:00am – 5:00pm Eastern Time.

**Warranty:** JLT Performance Inc. will repair or replace any part of their product found upon our inspection to be defective in workmanship or material within 1 year from the purchase date for the original purchaser.

**Disclaimer:** JLT Performance Inc. makes no warranties whatsoever, expressed or implied, oral or written to any purchasers, except the warranty above. JLT Performance Inc. hereby specifically excludes from any implied warranty of merchantability or implied warranty of incidental, secondary, or consequential damages of any kind whatsoever. All purchasers and users of products manufactured by JLT Performance Inc. agree to hold harmless and indemnify JLT Performance Inc. from any and all claims arising from their use. Failure to receive notice of any or the limitations contained in this disclaimer shall not serve to extend liability to JLT Performance Inc. for any claims arising out of use of its products.

**Custom Paint Disclaimer:** All custom paint jobs are done by JLT Performance Inc. Every job is different and done by hand. By ordering a custom paint job, you accept this fact and cannot hold JLT Performance liable for the end result not being exactly what you had in your mind.

**Return Policy:** All returns will be subject to a 10%-25% restocking fee. Air Filters will not be accepted for return unless they are in original plastic sealed bag. Please visit [www.JLTtruecoldair.com](http://www.JLTtruecoldair.com) for complete return policy.