



Scan QR Code with your smart phone for video instructions. Video can also be viewed on our website. See product details.

Remove stock PCV line you are replacing by releasing the plastic tangs and pull the hose off the fittings. Then install new JLT assembly in its place, done! **TO CHECK TANK: HOLD TOP FIRMLY AND UNSCREW BOTTOM. DO NOT TWIST TANK WHILE INSTALLED**



To properly clean the filter in the oil separator, remove it with a pick or small screw driver and spray any degreaser or solvent through it and let it air dry. Clean it every 5,000 miles. Thanks for the business. If you have any questions, please e-mail [Jay@JLTtruecoldair.com](mailto:Jay@JLTtruecoldair.com) or call 757-335-1940. Our hours are Monday-Friday. 8:00am – 5:00pm Eastern Time.

**Warranty:** JLT Performance Inc. will repair or replace any part of their product found upon our inspection to be defective in workmanship or material within 1 year from the purchase date for the original purchaser.

**Disclaimer:** JLT Performance Inc. makes no warranties whatsoever, expressed or implied, oral or written to any purchasers, except the warranty above. JLT Performance Inc. hereby specifically excludes from any implied warranty of merchantability or implied warranty of incidental, secondary, or consequential damages of any kind whatsoever. All purchasers and users of products manufactured by JLT Performance Inc. agree to hold harmless and indemnify JLT Performance Inc. from any and all claims arising from their use. Failure to receive notice of any or the limitations contained in this disclaimer shall not serve to extend liability to JLT Performance Inc. for any claims arising out of use of its products.

**Return Policy:** All returns will be subject to a 10%-25% restocking fee. Please visit [www.JLTtruecoldair.com](http://www.JLTtruecoldair.com) for complete return policy.