



## Part # 4418 10-12 Mustang GT/CS Chin Spoiler Splitter Combo

**Notice: Install new, unpainted parts according to these instructions!  
If Painting, remove parts, paint them and re-install.  
Painted or Altered Parts are Non-Refundable!  
(Excludes Cervini Pre-painted Parts)**

**Step 1**

Remove the factory Bumper from the car. (Save all factory mounting hardware!)

**Step 2**

Remove the factory Chin Spoiler from the Bumper. (Save all factory mounting hardware!)

**Step 3**

Install your new Cervini Chin Spoiler in the same mounting locations to the bumper using the factory hardware.

**Step 4 THIS STEP IS FOR THE OPTIONAL FOG LIGHT KIT ONLY!**

If you purchased the Optional Chin Spoiler / Splitter with Fog Light Kit, install the Lights to the plastic mounting pans. Install each mounting pan to the bumper using the included 8 silver screws.

**Step 5**

Install the wire harness extensions to the factory wire harness.

**Step 6**

Re-Install the bumper to the car.

**OPTIONAL FOG LIGHT HARDWARE**

QTY	DESCRIPTION	HARDWARE #
8	SILVER SCREWS	32144