



Smog Pump Eliminator Kit Installation Instructions

1. Remove hose attached to the back of the factory smog pump.
2. Remove the serpentine drive belt.
3. Remove the bolt from the bottom rear of the smog pump. Do not remove the metal brace attached to the timing cover.
4. Remove the top bolt from the smog pump.
5. Remove smog pump from the aluminum bracket.
6. Place smog pump eliminator in its place and loosely install the top bolt.
7. Position the eliminator and line up the bottom rear hole and loosely install the bolt.
8. Tighten both bolts and reinstall the serpentine drive belt.
9. Remove rubber smog hoses with valves and plug the vacuum lines.
10. Remove the metal crossover tube from the rear of the cylinder heads & use LRS-6086AK to plug the holes in the cylinder heads.
11. Remove the metal tube going to the H pipe and pinch off the h-pipe opening with a pair of pliers, or weld the hole shut.

****NOTE**** 1994-1995 may require minor clearance of the mounting bracket to clear the alternator.