



DOOR PANEL INSTALATION SHEET

Thank you for purchasing our door panels. Installing these panels are an easy way to enhance, and lighten up the interior of your street car, or race car. Here are a couple of helpful tips to install the door panels.

Step 1

Remove the original door panel. As crazy as it sounds people have tried to skip this step! If you are using the stock power windows, make sure the factory wires are not going to be pinched behind the SRF door panel when installed.

Step 2

To install the SRF door panel into position, slide the top of the door panel into the window track. Line up the panel so it is even from front to back. When it is positioned perfectly, the panel edges and bottom will line up with the stock sheet metal step in the door skin.

Step 3

When you are satisfied with the fit, you are now ready to lay out your pop rivet pattern. The pop rivets will run along the front, bottom, and the back of the panel. The spacing of the rivets is totally up to you, but we recommend spacing about 2 1/2 – 3 inches apart.

And with that you should have your SRF door panels installed, and looking good. If you have any questions about the panels, or with the installation process, please feel free to call us at,

Scott Rod Fabrications
419-704-2686